



Manufacturer	Product Reference	Equipment Reference	Price Original
--------------	-------------------	---------------------	----------------

Laser Printers Cartridges

Apple	M5893G/A (8500)	LaserWriter 8500 Printer	✓
Apple	M4683G/A (12/640)	LaserWriter 12/640 Printer	✓
Brother	DR200	HL-720/730/760/1040/1050/1060/1070 Series Printers	✓
Brother	DR300	HL-820/1050/1060/1070 Series Printers	✓
Brother	TN-04 Black	TBA	✓
Brother	TN-04 Cyan	TBA	✓
Brother	TN-04 Magenta	TBA	✓
Brother	TN-04 Yellow	TBA	✓
Brother	TN-130 Black	TBA	✓
Brother	TN-130 Cyan	TBA	✓
Brother	TN-130 Magenta	TBA	✓
Brother	TN-130 Yellow	TBA	✓
Brother	<i>New</i> TN-135 Black	TBA	✓
Brother	<i>New</i> TN-135 Cyan	TBA	✓
Brother	<i>New</i> TN-135 Magenta	TBA	✓
Brother	<i>New</i> TN-135 Yellow	TBA	✓
Brother	TN1700	HL-8050 Printers	✓
Brother	TN2000 (TN350 USA)	HL-2500 Printers	✓
Brother	DR2000 (DR 350 USA)	HL-2500 Printers	✓
Brother	<i>New</i> TN2005	TBA	✓
Brother	<i>New</i> DR2005	TBA	✓
Brother	TN2110/2120	HL-2140/2150 Printers	✓
Brother	DR2100	HL-2140/2150 Printers	✓
Brother	TN3030/3060 (TN540/70 USA)	HL-1030/1230/1240/1250/1270/1440/1450/1470 (Must include cover)	✓
Brother	<i>New</i> TN3130/70 (TN550/580 USA)	TBA	✓
Brother	<i>New</i> TN3230/80 - (TN620/650 (USA))	TBA	✓
Brother	DR3200 - (DR620 USA)	TBA	✓
Brother	DR3000 (DR510 USA)	HL-1030/1230/1240/1250/1270/1440/1450/1470	✓
Brother	DR3100 (DR520 USA)	TBA	✓
Brother	TN4100 (TN670 USA)	HL 1800 Series Printers (Must include cover)	✓
Brother	DR4000 (DR600 USA)	HL 1800 Series Printers	✓
Brother	TN5500 (TN700 USA)	HL 7050 / 7050N Series Printers (Must include cover)	✓
Brother	DR5500 (DR 700 USA)	HL 7050 / 7050N Series Printers	✓
Brother	TN6300/6600 (TN430/460 USA)	HL-1030/1230/1240/1250/1270/1440/1450/1470 (Must include cover)	✓
Brother	DR6000 (DR400 USA)	HL-1030/1230/1240/1250/1270/1440/1450/1470 (DR6000 Drum)	✓
Brother	TN7300/7600 (TN530/560 USA)	HL-1650/1850/1870N Printers (Must include cover)	✓
Brother	DR7000 (DR500 USA)	HL-1650/1850/1870N Printers	✓
Brother	DR8000	870P/MFc-9030/9070/9160/9108 Series Machines	✓
Canon	EP27	Laser shot LBP 3200	✓
Canon	A30/F41-4102	FC-1/2/3/3MK2/4/5/5MK2/22/PC-6/7/7RE/11 Personal Copiers	✓
Canon	E30/(Japan)	FC310/330 Series Copiers (Japanese origin Cartridge)	✓
Canon	E30/(France)	FC310/330 Series Copiers (Other than Japanese origin Cartridge)	✓
Canon	FX1	L700/760/770/780/790/3000/3300/1/9550 Fax Machines	✓
Canon	FX2	L500/L600 Fax Machines	✓
Canon	FX3	L250/L300/L350/Multipass/L60/L90/L260i Fax Machines	✓
Canon	FX4	L800/L900 Fax Machines	✓
Canon	FX6	L1000 Fax Machines	✓
Canon	FX7	L2000/iP2000 Machines	✓
Canon	FX10	L100/120 Fax Machine	✓
Canon	Type T (FX-8 USA)	PC-D320/340/L400 Machines (Type T)	✓
Canon	Type M (L50 USA)	TBA	✓
Dell	P1100/1110 (ML1610)	TBA	✓
Dell	MP1500 (E321)	MP1500 Series Printers	✓
Dell	P1600N (ML2250)	TBA	✓
Dell	P1700 (E330)	TBA	✓
Dell	P1700 Drum Unit	P1700 Series Printers	✓



Manufacturer	Product Reference	Equipment Reference	Price Original
Dell	P1720 (E250)	P1720 Series Printers	✓
Dell	<i>New</i> P1720 DRUM UNIT	TBA	✓
Dell	1815 (ML3050)	1815 Series Printers	✓
Dell	S2500 (T420)	2500 Series Printers	✓
Dell	MS5200 (T630)	MS5200 Series Printers	✓
Dell	5210 (T640)	MS5210 Series Printers	✓
Dell	1320CN (B)	Dell 1320 Series Colour Printers (Black Cart.)	✓
Dell	1320CN (C)	Dell 1320 Series Colour Printers (Cyan Cart.)	✓
Dell	1320CN (M)	Dell 1320 Series Colour Printers (Magenta Cart.)	✓
Dell	1320CN (Y)	Dell 1320 Series Colour Printers (Yellow Cart.)	✓
Dell	3000/3100CN (B)	Dell 3000/3100CN Colour Printers (Black Cart.)	✓
Dell	3000/3100CN (C)	Dell 3000/3100CN Colour Printers (Cyan Cart.)	✓
Dell	3000/3100CN (M)	Dell 3000/3100CN Colour Printers (Magenta Cart.)	✓
Dell	3000/3100CN (Y)	Dell 3000/3100CN Colour Printers (Yellow Cart.)	✓
Dell	3110/3115CN (B)	Dell 3110/3115CN Colour Printers (Black Cart.)	✓
Dell	3110/3115CN (C)	Dell 3110/3115CN Colour Printers (Cyan Cart.)	✓
Dell	3110/3115CN (M)	Dell 3110/3115CN Colour Printers (Magenta Cart.)	✓
Dell	3110/3115CN (Y)	Dell 3110/3115CN Colour Printers (Yellow Cart.)	✓
Dell	5100CN (B)	Dell 5100CN Colour Printers (Black Cart.)	✓
Dell	5100CN (C)	Dell 5100CN Colour Printers (Cyan Cart.)	✓
Dell	5100CN (M)	Dell 5100CN Colour Printers (Magenta Cart.)	✓
Dell	5100CN (Y)	Dell 5100CN Colour Printers (Yellow Cart.)	✓
Dell	5110CN (B)	Dell 5110CN Colour Printers (Black Cart.)	✓
Dell	5110CN (C)	Dell 5110CN Colour Printers (Cyan Cart.)	✓
Dell	5110CN (M)	Dell 5110CN Colour Printers (Magenta Cart.)	✓
Dell	5110CN (Y)	Dell 5110CN Colour Printers (Yellow Cart.)	✓
Epson	SO50005 (5500T)	EPL 5500 Printers (Toner Unit)	✓
Epson	SO51029 (5500D)	EPL 5500 Printers (Drum Unit)	✓
Epson	SO50010 (5700T)	EPL 5700/5800 Printers (Toner Unit)	✓
Epson	SO51055 (5700D)	EPL 5700/5800 Printers (Drum Unit)	✓
Epson	SO51070 (N2050)	TBA	✓
Epson	C13S050100 (AC900 Blk)	Epson Aculaser C900/1900 Colour Printer (Black Cart)	✓
Epson	C13S050100 (AC900 Yel)	Epson Aculaser C900/1900 Colour Printer (Yellow Cart.)	✓
Epson	C13S050100 (AC900 Mag)	Epson Aculaser C900/1900 Colour Printer (Magenta Cart)	✓
Epson	C13S050100 (AC900 Cyn)	Epson Aculaser C900/1900 Colour Printer (Cyan Cart)	✓
Epson	C13S050190 (1100 Blk)	Epson Aculaser C1100 Colour Printer (Black Cart)	✓
Epson	C13S050188/92 (1100 Mag)	Epson Aculaser C1100 Colour Printer (Magenta Cart)	✓
Epson	C13S050189/93 (1100 Cyan)	Epson Aculaser CC1100 Colour Printer (Cyan Cart)	✓
Epson	C13S050187/91 (1100 Yellow)	Epson Aculaser C1100 Colour Printer (Yellow Cart)	✓
HP	HP92274A (4L)	HP Laserjet 4L,4ML,4P,4MP Printers	✓
HP	HP92291A (NX)		✓
HP	HP92298A (EX)	HP Laserjet 4,4+,4M,4M+,5,5N & 5M Printers	✓
HP	HP92298X (EX)	HP Laserjet 4,4+,4M,4M+,5,5N & 5M Printers	✓
HP	HPC3900A (BX)	HP Laserjet 4M & 4MV Printers	✓
HP	HPC3903A (VX)	HP Laserjet 5P,5MP,6P & 6MP Printers	✓
HP	HPC3906A (AX)	HP Laserjet 3100,3150,5L & 6L Printers	✓
HP	HPC3909A (WX)	HP Laserjet 5si,5siMX & 8000 Printers + Mopier 240	✓
HP	HPC4092A (1100)	HP Laserjet 1100,1100A & 3200 Printers	✓
HP	HPC4096A (2100)	HP Laserjet 2100 & 2200 Printers	✓
HP	HPC4127A (4000A)	HP Laserjet 4000 & 4050 Printers	✓
HP	HPC4127X (4000X)	HP Laserjet 4000 & 4050 Printers	✓
HP	HPC4129X (5000)	HP Laserjet 5000,5000N & 5000GN Printers	✓
HP	HPC4182X (8100)	HP Laserjet 8100 & 8150 Printers + Mopier 320	✓
HP	HPQ2612A (1010)	HP Laserjet 1010 Printer	✓
HP	HPCB435A (1105)	HP Laserjet 1105/1106 Printer	✓
HP	HPCB436A (1120)	HP Laserjet 1120/1522/P1505 Printer	✓
HP	HPQ2624A (1150)	HP Laserjet 1150 Printers	✓
HP	HPC7115A (1200A)	HP Laserjet 1200 & 1220 Printers	✓



Manufacturer	Product Reference	Equipment Reference	Price Original
HP	HPC7115X (1200X)	HP Laserjet 1200 & 1220 Printers	✓
HP	HPQ2613A (1300)	HP Laserjet 1300 Printers	✓
HP	HPQ2613X (1300)	HP Laserjet 1300 Printers	✓
HP	HPQ7516A (J5200)	HP Laserjet 5200 Series Printers	✓
HP	HPQ7551A (P3005)	HP Laserjet P3005 Series Printers	✓
HP	HPQ7551X (P3005)	HP Laserjet P3005 Series Printers	✓
HP	HPQ7553A (P2015)	HP Laserjet P2015 Series Printers	✓
HP	HPQ7553X (P2015)	HP Laserjet P2015 Series Printers	✓
HP	HPQ7570A (M5025)	HP Laserjet M5025 Series Printers	✓
HP	HPQ5945A	HP Laserjet 4345 Printers	✓
HP	HPCE505A	HP Laserjet P2035 Series Printers	✓
HP	HPCE505X	HP Laserjet P2035 Series Printers	✓
HP	HPQ5949A (1320)	HP Laserjet 1320/1160 Printers	✓
HP	HPQ5949X (1320)	HP Laserjet 1320/1160 Printers	✓
HP	HPC8061A)4100A)	HP Laserjet 4100 Printers	✓
HP	HPC8061X (4100X)	HP Laserjet 4100 Printers	✓
HP	HPQ1338A (4200)	HP Laserjet 4200 Printers	✓
HP	HPQ1339A (4300)	HP Laserjet 4300 Printers	✓
HP	HPQ5942A (42/4350)	HP Laserjet 4250 Printers	✓
HP	HPQ5942X (42/4350)	HP Laserjet 4350 Printers	✓
HP	HPQ2610A (2300)	HP Laserjet 2300 Printers	✓
HP	HPQ6511A (2410)	HP Laserjet 2420/10/20/30 Printers	✓
HP	HPQ6511X (2410)	HP Laserjet 2420/10/20/30 Printers	✓
HP	HPC8543X (9000)	HP Laserjet 9000 Printers	✓
HP	HPCC364A (P4014)	HP Laserjet P4014 series printers	✓
HP	HPCC364X (P4015/4515)	HP Laserjet P4015/4515 Series Printers	✓
HP	HP CE250A (Blk)	TBA	✓
HP	HP CE251A (Cyan)	TBA	✓
HP	HP CE252A (Yellow)	TBA	✓
HP	HP CE253A (Magenta)	TBA	✓
HP	<i>New</i> HP CE250S (Blk) (Starter Cart.)	TBA	✓
HP	<i>New</i> HP CE251S (Cyan) (Starter Cart.)	TBA	✓
HP	<i>New</i> HP CE252S (Yellow) (Starter Cart.)	TBA	✓
HP	<i>New</i> HP CE253S (Magenta) (Starter Cart.)	TBA	✓
HP	HP CB380A (CP6015 BLK)	HP Laserjet CP6015 Series Colour Printer (Blk Cartridge)	✓
HP	HP CB390A (CP6030/6040 Blk)	HP Laserjet CP6030 Series Colour Printer (Blk Cartridge)	✓
HP	HP CB381A (CP6015/6030/6040 Cyan)	HP Laserjet CP6030 Series Colour Printer (Cyan Cartridge)	✓
HP	HP CB382A (CP6015/6030/6040 Yel)	HP Laserjet CP6030 Series Colour Printer (Yellow Cartridge)	✓
HP	HP CB383A (CP6015/6030/6040 Mag)	HP Laserjet CP6030 Series Colour Printer (Magenta Cartridge)	✓
HP	HP CB400A (CP4005)	HP Laserjet CP4005 Printers (Black Cartridge)	✓
HP	HP CB401A (CP4005)	HP Laserjet CP4005 Printers (Cyan Cartridges)	✓
HP	HP CB402A (CP4005)	HP Laserjet CP4005 Printers (Yellow Cartridges)	✓
HP	HP CB403A (CP4005)	HP Laserjet CP4005 Printers (Magenta Cartridges)	✓
HP	HP CB540A (1215/1515/1518 BLK)	HP Laserjet 1215 Series Colour Printer (Black Cartridge)	✓
HP	HP CB541A (1215/1515/1518 Cyan)	HP Laserjet 1215 Series Colour Printer (Cyan Cartridge)	✓
HP	HP CB542A (1215/1515/1518 Yel)	HP Laserjet 1215 Series Colour Printer (Yellow Cartridge)	✓
HP	HP CB543A (1215/1515/1518 Mag)	HP Laserjet 1215 Series Colour Printer (Magenta Cartridge)	✓
HP	<i>New</i> HP CB540S (BLK) (Starter Cart.)	HP Laserjet 1215 Series Colour Printer (Black Cartridge)	✓
HP	<i>New</i> HP CB541S (Cyan) (Starter Cart.)	HP Laserjet 1215 Series Colour Printer (Cyan Cartridge)	✓
HP	<i>New</i> HP CB542S (Yel) (Starter Cart.)	HP Laserjet 1215 Series Colour Printer (Yellow Cartridge)	✓
HP	<i>New</i> HP CB543S (Mag) (Starter Cart.)	HP Laserjet 1215 Series Colour Printer (Magenta Cartridge)	✓
HP	HP CC530 A (Blk)	TBA	✓
HP	HP CC531A (Cyan)	TBA	✓
HP	HP CC532A (Yellow)	TBA	✓
HP	HP CC533A (Magenta)	TBA	✓
HP	<i>New</i> HP CC530S (Blk) (Starter Cart.)	TBA	✓
HP	<i>New</i> HP CC531S (Cyan) (Starter Cart.)	TBA	✓



Manufacturer	Product Reference	Equipment Reference	Price Original
HP	New HP CC532S (Yellow) (Starter Cart.)	TBA	✓
HP	New HP CC533S (Magenta) (Starter Cart.)	TBA	✓
HP	HPQ6000A (Blk)	HP Laserjet 2600 Printers (Black Cartridge)	✓
HP	HPQ6001A (Cyan)	HP Laserjet 2600 Printers (Cyan Cartridges)	✓
HP	HPQ6002A (Yellow)	HP Laserjet 2600 Printers (Yellow Cartridges)	✓
HP	HPQ6003A (Magenta)	HP Laserjet 2600 Printers (Magenta Cartridges)	✓
HP	HPC9700A (2500 BLK)	HP Laserjet 2500 Printers (Black Cartridge)	✓
HP	HPC9701A (2500CYN)	HP Laserjet 2500 Printers (Cyan Cartridges)	✓
HP	HPC9702A (2500YEL)	HP Laserjet 2500 Printers (Yellow Cartridges)	✓
HP	HPC9703A (2500MAG)	HP Laserjet 2500 Printers (Magenta Cartridges)	✓
HP	HPQ3960A(BLK)	HP Laserjet 2550 Printers (Black Cartridge)	✓
HP	HPQ3961A(cyan)	HP Laserjet 2550 Printers (Cyan Cartridges)	✓
HP	HPQ3962A(Yel)	HP Laserjet 2550 Printers (Yellow Cartridges)	✓
HP	HPQ3963A(Mag)	HP Laserjet 2550 Printers (Magenta Cartridges)	✓
HP	New HPQ3964A(Drum)	TBA	✓
HP	New HPQ3971A(cyan)	TBA	✓
HP	New HPQ3972A(Yel)	TBA	✓
HP	New HPQ3973A(Mag)	TBA	✓
HP	HPC9720A (4600 BLK)	HP Laserjet 4600 Printers (Black Cartridge)	✓
HP	HPC9721A (4600CYN)	HP Laserjet 4600 Printers (Cyan Cartridges)	✓
HP	HPC9722A (4600YEL)	HP Laserjet 4600 Printers (Yellow Cartridges)	✓
HP	HPC9723A (4600MAG)	HP Laserjet 4600 Printers (Magenta Cartridges)	✓
HP	HPQ5950 (4700 BLK)	HP Laserjet 4700 Printers (Black Cartridge)	✓
HP	HPQ5951 (4700 Cyan)	HP Laserjet 4700 Printers (Cyan Cartridge)	✓
HP	HPQ5952 (4700 Magenta)	HP Laserjet 4700 Printers (Magenta Cartridge)	✓
HP	HPQ5953 (4700 Yellow)	HP Laserjet 4700 Printers (Yellow Cartridge)	✓
HP	HPQ6460 (4730 BLK)	HP Laserjet 4730 Printers (Black Cartridge)	✓
HP	HPQ6461 (4730 Cyan)	HP Laserjet 4730 Printers (Cyan Cartridge)	✓
HP	HPQ6462 (4730 Yellow)	HP Laserjet 4730 Printers (Magenta Cartridge)	✓
HP	HPQ6463 (4730 Magenta)	HP Laserjet 4730 Printers (Yellow Cartridge)	✓
HP	HPC9730A (5500 BLK)	HP Laserjet 5500 Printers (Black Cartridge)	✓
HP	HPC9731A (5500CYN)	HP Laserjet 5500 Printers (Cyan Cartridges)	✓
HP	HPC9732A (5500YEL)	HP Laserjet 5500 Printers (Yellow Cartridges)	✓
HP	HPC9733A (5500MAG)	HP Laserjet 5500 Printers (Magenta Cartridges)	✓
HP	HPQ7560 (3000 Blk)	HP Laserjet 3000 Printers (Black Cartridge)	✓
HP	HPQ7561 (3000 Cyan)	HP Laserjet 3000 Printers (Cyan Cartridge)	✓
HP	HPQ7562 (3000 Yellow)	HP Laserjet 3000 Printers (Yellow Cartridge)	✓
HP	HPQ7563 (3000 Magenta)	HP Laserjet 3000 Printers (Magenta Cartridge)	✓
HP	HPQ2670A (35/3700 BLK)	HP Laserjet 3500 Printers (Black Cartridge)	✓
HP	HPQ2671A (3500 CYN)	HP Laserjet 3500 Printers (Cyan Cartridge)	✓
HP	HPQ2672A (3500 YEL)	HP Laserjet 3500 Printers (Yellow Cartridge)	✓
HP	HPQ2673A (3500 MAG)	HP Laserjet 3500 Printers (Magenta Cartridge)	✓
HP	HPQ6470 (3600 Blk)	HP Laserjet 3600 Printers (Black Cartridge)	✓
HP	HPQ6471 (3600 Cyan)	HP Laserjet 3600 Printers (Cyan Cartridge)	✓
HP	HPQ6472 (3600 Yellow)	HP Laserjet 3600 Printers (Yellow Cartridge)	✓
HP	HPQ6473 (3600 Magenta)	HP Laserjet 3600 Printers (Magenta Cartridge)	✓
HP	HPQ2681A (3700 CYN)	HP Laserjet 3700 Printers (Cyan Cartridges)	✓
HP	HPQ2682A (3700 YEL)	HP Laserjet 3700 Printers (Yellow Cartridges)	✓
HP	HPQ2683A (3700 MAG)	HP Laserjet 3700 Printers (Magenta Cartridges)	✓
HP	HPQ7581A (3800 CYN)	HP Laserjet 3800 Printers (Cyan Cartridges)	✓
HP	HPQ7582A (3800 YEL)	HP Laserjet 3800 Printers (Yellow Cartridges)	✓
HP	HPQ7583A (3800 MAG)	HP Laserjet 3800 Printers (Magenta Cartridges)	✓
IBM	90H3566 (N32)	IBM N32 Series Printers	✓
IBM	63H2401 (NP17)	IBM NP17 Series Printers	✓
IBM	28P2494 (1120/1125)	IBM 1120/1125 Laser Printers	✓
IBM	38L1410 (I/Print 21)	IBM Infoprint 21 series Laser Printers	✓
IBM	28P2010 (1130/1140)	IBM 1130/1140 Laser Printers	✓
IBM	28P2406 (1116)	IBM 1116 Laser Printers	✓



Manufacturer	Product Reference	Equipment Reference	Price Original
IBM	28P18820 (1145) (W820)	IBM 1145 Series Printers	✓
IBM	53P2493/4(1222) (T420)	IBM 1222 Series Printers	✓
IBM	75P4302/3(1352) (T630)	IBM 1332/1352 Series Printers	✓
IBM	39V0542 (1570) (IP1332)	TBA	✓
IBM	75P4684 (1312) (E321)	TBA	✓
IBM	New 39V1638 (E250)	TBA	✓
IBM	New 39V3202 (E260)	TBA	✓
IBM	75P5710/11 (1412) (E330)	TBA	✓
IBM	New 39V1641/42 (E350)	TBA	✓
IBM	New 39V1640/44 (E450)	TBA	✓
IBM	New 39V3206 (E460)	TBA	✓
IBM	75P6959/61 (1532) (T640)	IBM 1532 Series Printers	✓
Kyocera	TK-11	TBA	✓
Kyocera	TK-17	TBA	✓
Kyocera	TK-18	TBA	✓
Kyocera	TK-30	TBA	✓
Kyocera	TK-50	TBA	✓
Kyocera	TK-60	TBA	✓
Kyocera	TK-65	TBA	✓
Kyocera	TK-70	TBA	✓
Kyocera	TK-110	TBA	✓
Kyocera	TK-120	TBA	✓
Kyocera	TK-330	TBA	✓
Kyocera	TK-400	TBA	✓
LEX	1380520 (4019)	IBM/Lexmark 4019 Laser Printers (Std)	✓
LEX	1380850 (7k) (4039)	IBM/Lexmark 4039 Laser Printers (Std)	✓
LEX	1380950(12.8k)(4039)	IBM/Lexmark 4039 Laser Printers (Marathon)	✓
LEX	1382100 (7k) (4049)	IBM/Lexmark 4049 Laser Printers (Std)	✓
LEX	1382150 (14k)(4049)	IBM/Lexmark 4049 Laser Printers (Marathon)	✓
LEX	69G8256 (O/ E Toner)	Lexmark Optra E Laser Printers	✓
LEX	69G8257 (O/E Drum)	Lexmark Optra E Laser Printers	✓
LEX	12016SE (E120 Toner)	TBA	✓
LEX	12026XW (E120 Drum)	TBA	✓
LEX	10S0150 (E210)	Lexmark Optra E210 Printers	✓
LEX	12S0300/400 (E220)	Lexmark Optra E220 Printers	✓
LEX	E250A11E (E250 Toner)	TBA	✓
LEX	E250X22G (E250 Drum)	TBA	✓
LEX	New E260 (Toner)	TBA	✓
LEX	13T0101(E310)	Lexmark Optra E310 Series Printers	✓
LEX	0008A0475/6/7/8 (E320)	Lexmark E320, E322 series printers	✓
LEX	12A7400/05 (E321)	Lexmark E321 series printers	✓
LEX	12A8300/5/8400/5(E330)	Lexmark E330/332 Series Printers	✓
LEX	12A8302 (E330 OPC)	TBA	✓
LEX	E352H11E (E350)	TBA	✓
LEX	New E360	TBA	✓
LEX	New E450	TBA	✓
LEX	New E460	TBA	✓
LEX	1382620/5/920/5 (OPTRA S)	Lexmark Optra S/1382620/1382625/1382920/1382925	✓
LEX	12A0725/825/829 (OPTRA SE)	Lexmark Optra SE Series Printers	✓
LEX	17G0152/4/4K00199(OPT M)	Lexmark Optra M410/412 Printers	✓
LEX	12A5740/5/840/5/9 (OPT T610)	Lexmark Optra T /12A5740/5745/5840/5845/5849	✓
LEX	12A7310/5/410/5 (T420)	Lexmark T420 (20g0100/0130)	✓
LEX	12A8320/5/420/5 (T430)	Lexmark Optra T430 (12A8320/8325/8420/8425)	✓
LEX	0012A6730/5/830/5/9 (T520)	Lexmark T520/T522 (12A6730/6735/6830/6835)	✓
LEX	0012A6760/5/860/5/9 (T620)	Lexmark T620/T622 (12A6760/6765/6860/6865)	✓
LEX	12A7360/2/5/460/5 (T630)	Lexmark T630 (12A7360/7365/7460/7465)	✓
LEX	T632	TBA	✓
LEX	20g0100/0130 (T640)	Lexmark T640 Series Printers	✓



Manufacturer	Product Reference	Equipment Reference	Price Original
LEX	20g0200/230 (T642)	Lexmark T642 series printers	✓
LEX	20g0300/0560 (T644)	Lexmark T644 series printers	✓
LEX	<i>New</i> T650	TBA	✓
LEX	<i>New</i> T654	TBA	✓
LEX	12B0090 (W820)	Lexmark W820 Printers	✓
LEX	W840 Toner	TBA	✓
LEX	W840 Drum	TBA	✓
LEX	C500 Black	TBA	✓
LEX	C500 Yellow	TBA	✓
LEX	C500 Magenta	TBA	✓
LEX	C500 Cyan	TBA	✓
LEX	C510 Black	TBA	✓
LEX	C510 Yellow	TBA	✓
LEX	C510 Magenta	TBA	✓
LEX	C510 Cyan	TBA	✓
LEX	C522/524 Black	TBA	✓
LEX	C522/524 Yellow	TBA	✓
LEX	C522/524 Magenta	TBA	✓
LEX	C522/524 Cyan	TBA	✓
LEX	C910 Black	TBA	✓
LEX	C910 Yellow	TBA	✓
LEX	C910 Magenta	TBA	✓
LEX	C910 Cyan	TBA	✓
LEX	C920 Black	TBA	✓
LEX	C920 Yellow	TBA	✓
LEX	C920 Magenta	TBA	✓
LEX	C920 Cyan	TBA	✓
LEX	18S0090 (X215)	TBA	✓
LEX	X340/342	TBA	✓
LEX	X422	TBA	✓
LEX	X642/644/646	TBA	✓
LEX	<i>New</i> X651/2/4/6/8	TBA	✓
LEX	<i>New</i> X654/6/8	TBA	✓
LEX	X850/852/854	TBA	✓
OKI	OKI 5100 (Black)	Oki C5100 Colour Printers (Black Cartridge)	✓
OKI	OKI 5100 (Cyan)	Oki C5100 Colour Printers (Cyan Cartridge)	✓
OKI	OKI 5100 (Yellow)	Oki C5100 Colour Printers (Magenta Cartridge)	✓
OKI	OKI 5100 (Magenta)	Oki C5100 Colour Printers (Yellow Cartridge)	✓
OKI	Oki 5600/5700 (Blk)	TBA	✓
OKI	Oki 5600/5700 (Cyan)	TBA	✓
OKI	Oki 5600/5700 (Magenta)	TBA	✓
OKI	Oki 5600/5700 (Yellow)	TBA	✓
OKI	Oki 7200 (Blk)	Oki C7200 Colour Printers (Black Cartridge)	✓
OKI	Oki 7200 (Cyan)	Oki C7200 Colour Printers (Cyan Cartridge)	✓
OKI	Oki 7200 (Magenta)	Oki C7200 Colour Printers (Magenta Cartridge)	✓
OKI	Oki 7200 (Yellow)	Oki C7200 Colour Printers (Yellow Cartridge)	✓
OKI	Oki 8600/8800 (Blk)	TBA	✓
OKI	Oki 8600/8800 (Cyan)	TBA	✓
OKI	Oki 8600/8800 (Magenta)	TBA	✓
OKI	Oki 8600/8800 (Yellow)	TBA	✓
OKI	Oki 9200 (Blk)	Oki C9200 Colour Printers (Black Cartridge)	✓
OKI	Oki 9200 (Cyan)	Oki C9200 Colour Printers (Cyan Cartridge)	✓
OKI	Oki 9200 (Magenta)	Oki C9200 Colour Printers (Magenta Cartridge)	✓
OKI	Oki 9200 (Yellow)	Oki C9200 Colour Printers (Yellow Cartridge)	✓
Panafax	UG3309AU (744)	Panafax UF-744/788 Fax Machines	✓
Panafax	UG3204 (745)	Panafax UF-745/755 Fax Machines	✓
Panafax	UG3313AG (550)	Panafax UF-550/560/770/880/885/895/DF1100/DX1000	✓
Panafax	UG3350AG (585)	Panafax UF-585/595 Fax Machines	✓



Manufacturer	Product Reference	Equipment Reference	Price Original
QMS	Magicolor 2300 Blk	Magicolor 2300 Colour Printers (B) (Must have Yellow Plastic cover)	✓
QMS	Magicolor 2300 Yel	Magicolor 2300 Colour Printers (Y) (Must have Yellow Plastic cover)	✓
QMS	Magicolor 2300 Mag	Magicolor 2300 Colour Printers (M) (Must have Yellow Plastic cover)	✓
QMS	Magicolor 2300 Cyn	Magicolor 2300 Colour Printers (C) (Must have Yellow Plastic cover)	✓
QMS	Magicolor 2400 (BLK)	Magicolor 2400 Colour Printers (B) (Must have Yellow Plastic cover)	✓
QMS	Magicolor 2400 (Yellow)	Magicolor 2400 Colour Printers (Y) (Must have Yellow Plastic cover)	✓
QMS	Magicolor 2400 (Magenta)	Magicolor 2400 Colour Printers (M) (Must have Yellow Plastic cover)	✓
QMS	Magicolor 2400 (Cyan)	Magicolor 2400 Colour Printers (C) (Must have Yellow Plastic cover)	✓
S/sung	ML 1210	ML1210 Series printers	✓
S/sung	ML 1650	ML1650 Series Printers	✓
S/sung	SF5800	SF5800 series printers	✓
S/sung	SF6800	SF6800 Series Printers	✓
S/sung	ML6000	ML6000 Series printers	✓
S/sung	ML1520	ML 1520 Series Printers	✓
S/sung	ML1610	ML 1610 Series Printers	✓
S/sung	ML1630	ML 1630 Series Printers	✓
S/sung	ML1640	ML 1640 Series Printers	✓
S/sung	ML2010	ML 2010 Series Printers	✓
S/sung	SCX 4321/4521	SCX 4521 Series Printers	✓
S/sung	SCX4720	TBA	✓
S/sung	SCX4725	TBA	✓
S/sung	SCX 5312 Toner	TBA	✓
S/sung	SCX 5312 Drum	TBA	✓
S/sung	SCX 5530	TBA	✓
S/sung	SCX-6120 Toner	TBA	✓
S/sung	SCX-6120 Drum	TBA	✓
S/sung	SCX-6345 Toner	TBA	✓
S/sung	SCX-6345 Drum	TBA	✓
S/sung	ML 1510/1710	ML1710 SCX 4206/16/26 Series Printers	✓
S/sung	ML4500	SF4500 series printers	✓
S/sung	SF5100	SF5100 Series Printers	✓
S/sung	ML 6060	ML6060 Series printers	✓
S/sung	ML2150	ML 2150 Series Printers	✓
S/sung	ML2250	ML 2250 Series Printers	✓
S/sung	ML-2510	TBA	✓
S/sung	ML2550	ML 2550 Series Printers	✓
S/sung	ML2850/2851	ML 2850/2851 Series Printers	✓
S/sung	ML-3050	ML 3050 Series Printers	✓
S/sung	ML-4050/4550/4551	ML 4050 Series Printers	✓
S/sung	ML-3470/3471	ML 3470 Series Printers	✓
S/sung	ML-3560	ML 3560 Series Printers	✓
S/sung	SCX4100	SCX 4100 Series Printers	✓
S/sung	SCX4200	SCX 4200 Series Printers	✓
S/sung	SCX4300	SCX 4300 Series Printers	✓
S/sung	SCX4824/4828	SCX 4824 Series Printers	✓
S/sung	CLP-300 (B)	TBA	✓
S/sung	CLP-300 (C)	TBA	✓
S/sung	CLP-300) (M)	TBA	✓
S/sung	CLP-300 (Y)	TBA	✓
S/sung	CLP500(Blk)	CLP500 Series Colour Laser Printers (Black)	✓
S/sung	CLP500(Magenta)	CLP500 Series Colour Laser Printers (Magenta)	✓
S/sung	CLP500(Cyan)	CLP500 Series Colour Laser Printers (Cyan)	✓
S/sung	CLP500(Yellow)	CLP500 Series Colour Laser Printers (Yellow)	✓
S/sung	CLP510(Blk)	CLP510 Series Colour Laser Printers (Black)	✓
S/sung	CLP510(Cyan)	CLP510 Series Colour Laser Printers (Cyan)	✓
S/sung	CLP510(Magenta)	CLP510 Series Colour Laser Printers (Magenta)	✓
S/sung	CLP510(Yellow)	CLP510 Series Colour Laser Printers (Yellow)	✓
S/sung	CLP600(Blk)	TBA	✓



Manufacturer	Product Reference	Equipment Reference	Price Original
S/sung	CLP600(Cyan)	TBA	✓
S/sung	CLP600(Magenta)	TBA	✓
S/sung	CLP600(Yellow)	TBA	✓
S/sung	CLP610(Blk)	TBA	✓
S/sung	CLP610(Cyan)	TBA	✓
S/sung	CLP610(Magenta)	TBA	✓
S/sung	CLP610(Yellow)	TBA	✓
Sharp	AL 1000	Sharp A11000 series Printers	✓
Xerox	113R00184 (N40)	Xerox N24/N32/N40/3225/4025 Printers	✓
Xerox	113R0095 (NP17)	Xerox 4517/MP/D/MPD/Docuprint N17 Printers	✓

Inkjet Printer Cartridges

Canon	BC-01	BJ-10E/EX/SX/V/20 Printers + B200/200S Fax's	✓
Canon	BC-02	BJ-200/E/EX/230 + BJC-150/210 Printers	✓
Canon	BC-05	BJC-150/210/240/250/1000 Printers	✓
Canon	BC-20	BJC-4000/4100/4200/4300/4400/4550/4650/5000/5100/5500Printers	✓
Canon	BX-2	B320/340/360 Fax Machines	✓
Canon	BX-3	B100/110/150/155 Fax Machines +MP10	✓
Canon	BX-20	Multipass 20/30/50	✓
Canon	PG-37	TBA	✓
Canon	CL-38	TBA	✓
Canon	PG-40	TBA	✓
Canon	PG-50	TBA	✓
Canon	CL-41	TBA	✓
Canon	CL-51	TBA	✓
Canon	CL-52 Photo	TBA	✓
Canon	PGI-5 Black	TBA	✓
Canon	CLI-8 Black	TBA	✓
Canon	CLI-8 Cyan	TBA	✓
Canon	CLI-8 Magenta	TBA	✓
Canon	CLI-8 Yellow	TBA	✓
Canon	CLI-8 Lt Cyan	TBA	✓
Canon	CLI-8 Lt Magenta	TBA	✓
Dell	T0529	Dell A720/920 Series Printers	✓
Dell	T0530	Dell A720/920 Series Printers	✓
Dell	T0601	Dell J 740 Series Printers	✓
Dell	T0602	Dell J 740 Series Printers	✓
Dell	M4640	TBA	✓
Dell	M4646	TBA	✓
Dell	Series 6 (JF333)	TBA	✓
Dell	Series 7 Black	TBA	✓
Dell	Series 7 Colour	TBA	✓
Dell	Series 8 MJ264 Black	TBA	✓
Dell	Series 9 Black	TBA	✓
Dell	Series 9 Colour	TBA	✓
Dell	7Y743	A940/A960 Printers	✓
Dell	7Y745	A940/A960 Printers	✓
Dell	Series 10 GM720 Black	TBA	✓
Dell	Series 10 UN398 Colour	TBA	✓
Dell	Series 11 KX701 Black	TBA	✓
Dell	Series 11 KX703 Colour	TBA	✓
HP	HP51626A/G	Deskjet 500/500C/510/520/540/550C/560C Printers	✓
HP	HP51625A	Deskjet Portable/310/320/340/340C/500C/540/550C/560C	✓
HP	HP51629A/G	Deskjet 600/660/670/690C/694C/695C Officejet 500/590	✓
HP	HP51633M	Deskjet Portable/310/320/340/340C Printers	✓
HP	HP51645A/G	Deskjet 710C/720/815C/820Cxi/850C/870Cxi/880C/890C/895Cxi/930C	✓
HP	HP51649A/N	Deskjet 350C/350CBI/600/610C/612C/640C/660C/670C/690C Printers	✓



Manufacturer	Product Reference	Equipment Reference	Price Original
HP	HPC1823D/G	Deskjet 710C/720/810C/815C/880C/895Cxi/1120C/	✓
HP	HPC6578A/D	Deskjet 930C/950C/970Cxi/990Cxi/1220C/G55/G85/G95/K60/K80	✓
HP	HPC6614D	Deskjet 610C/612C/640C Printers	✓
HP	HPC6615D	Deskjet 810C/840C/843C/PSC500 Printers	✓
HP	HPC6625A	Deskjet 840C/843C Printers	✓
HP	HPC6628A	Deskjet 350C/350CBI Printers	✓
HP	HPCB334A (54)	TBA	✓
HP	HPC6656A (56)	Deskjet 5550 Photosmart 7150/7350/5552 Printers	✓
HP	HPC6657A (57)	Photosmart 100 Printers	✓
HP	HPC6658A (58)	Deskjet 5550 Photosmart 7150/7350/5552 Printers	✓
HP	HPC9359A (59)	TBA	✓
HP	HPC8727A (27)	Deskjet 3320/3420 Printers	✓
HP	HPC8728A (28)	Deskjet 3320/3420 Printers	✓
HP	HPC 9351A (21)+XL	TBA	✓
HP	<i>New</i> HPC 9351G/A-LOW CAPACITY (21)	TBA	✓
HP	HPC 9352A (22)+XL	TBA	✓
HP	<i>New</i> HPC 9352G/A-LOW CAPACITY (22)	TBA	✓
HP	HPC 9368A (100)	TBA	✓
HP	HPC 9365A (101)	TBA	✓
HP	HPC 9360A (102)	TBA	✓
HP	HPCB 304AE (110)	TBA	✓
HP	HPCC640E (300 Black) +XL	TBA	✓
HP	HPCC643E (300 Colour) +XL	TBA	✓
HP	HPC 9362E (336)	TBA	✓
HP	HPC 9364E (337)	TBA	✓
HP	HPC 8765E (338)	TBA	✓
HP	HPC 8767E (339)	TBA	✓
HP	HPC 9361E (342)	TBA	✓
HP	HPC 8766E (343)	TBA	✓
HP	HPC 9363E (344)	TBA	✓
HP	HPC 9369E (348)	TBA	✓
HP	HPC 8335E (350)	TBA	✓
HP	HP CB336E (350XL)	TBA	✓
HP	HPC 8337E (351)	TBA	✓
HP	HP CB338E (351XL)	TBA	✓
Lex	10N0016	Z13/23/25/33/35 Printers	✓
Lex	10N0026	Z13/23/25/33/35 Printers	✓
Lex	10N0217	Z13/23/25/33/35 Printers	✓
Lex	10N0227	Z13/23/25/33/35 Printers	✓
Lex	12A1970/75	Colour Jetprinter Z11/Z31/Z42/Z51/Z52/3200/5000/5700/7000/7200	✓
Lex	12A1980/85	Colour Jetprinter Z11/Z31/3200/5000/5700/7000/7200 Printers	✓
Lex	12A1990	Colour Jetprinter Z22/Z31/Z32/3200/5000/5700/7000/7200	✓
Lex	13400HC	Colour Jetprinter 1000/1020/1100/2030/2030PE/2050/2050PE/3000 Pts	✓
Lex	15M0120/25	Colour Jetprinter Z42/Z51/Z52	✓
Lex	17G0050	Colour Jetprinter Z12/Z22/Z32 Printers	✓
Lex	17G0060	Colour Jetprinter Z12/Z22/Z32 Printers	✓
Lex	18L0032 (82)	Z55/65/65N Printers	✓
Lex	18L0042 (83)	Z55/65/65N Printers	✓
Lex	No. (1)	TBA	✓
Lex	No. (2)	TBA	✓
Lex	No. (3)	TBA	✓
Lex	No. (4)	TBA	✓
Lex	No. (5)	TBA	✓
Lex	<i>New</i> No. (14)	TBA	✓



Manufacturer	Product Reference	Equipment Reference	Price Original
Lex	<i>New</i> No. (14A)	TBA	✓
Lex	<i>New</i> No. (15)	TBA	✓
Lex	<i>New</i> No. (15A)	TBA	✓
Lex	<i>New</i> 18C1523 (23)	TBA	✓
Lex	<i>New</i> No. (23A)	TBA	✓
Lex	<i>New</i> 18C1524 (24)	TBA	✓
Lex	<i>New</i> No. (24A)	TBA	✓
Lex	<i>New</i> No. 28 Cart. Black	TBA	✓
Lex	<i>New</i> No. (28A)	TBA	✓
Lex	<i>New</i> No. 29 Cart. Colour	TBA	✓
Lex	<i>New</i> No. (29A)	TBA	✓
Lex	18C0031e (31)	Colour Jetprinter	✓
Lex	18C0032e (32)	Colour Jetprinter	✓
Lex	18C0033e (33)	Colour Jetprinter	✓
Lex	18C0034e (34)	Colour Jetprinter	✓
Lex	18C0035e (35)	Colour Jetprinter	✓
Lex	<i>New</i> No. (36)	TBA	✓
Lex	<i>New</i> No. (36A)	TBA	✓
Lex	<i>New</i> No. (36XL)	TBA	✓
Lex	<i>New</i> No. (36XLA)	TBA	✓
Lex	<i>New</i> No. (37)	TBA	✓
Lex	<i>New</i> No. (37A)	TBA	✓
Lex	<i>New</i> No. (37XL)	TBA	✓
Lex	<i>New</i> No. (37XLA)	TBA	✓
Lex	<i>New</i> No. (40)	TBA	✓
Lex	<i>New</i> No. (41)	TBA	✓
Lex	<i>New</i> No. (41A)	TBA	✓
Lex	<i>New</i> No. (42)	TBA	✓
Lex	<i>New</i> No. (42A)	TBA	✓
Lex	No. (43XL)	TBA	✓
Lex	No. (44XL)	TBA	✓
Lex	No. 45 Cart. Colour	TBA	✓
S/sung	M40	Samsung fax	✓
S/sung	M55	Samsung fax	✓
Sharp	UX-C70B	Sharp fax	✓

Postage Meter Cartridges

Neopost	IJ-25	IJ-25	✓
Neopost	IJ-35	IJ-35	✓
Neopost	IJ-65	IJ-65	✓
Neopost	IJ-90 Printhead	IJ-90 Printhead	✓
Neopost	IJ-90 Ink Tank	IJ-90 Ink Tank	✓
F/P	F/P Mymail Cartridge	F/P Mymail Cartridge	✓
F/P	F/P Ultimail Cartridge	F/P Ultimail Cartridge	✓

Non Virgin Laser Printers Cartridges



Manufacturer	Product Reference	Equipment Reference	Price Original
Brother	TN2000 (TN350 USA)	HL-2500 Printers	✓
Brother	TN3130/70 (TN550/580 USA)	TBA	✓
HP	HPQ2612A (1010)	HP Laserjet 1010 Printer	✓
HP	HPQ1338A (4200)	HP Laserjet 4200 Printers	✓
HP	HPQ5942X (42/4350)	HP Laserjet 4350 Printers	✓
HP	HPQ5949X (1320)	HP Laserjet 1320/1160 Printers	✓
HP	HPQ7551X (P3005)	HP Laserjet P3005 Series Printers	✓
HP	HPQ7553X (P2015)	HP Laserjet P2015 Series Printers	✓
LEX	12A7360/2/5/460/5 (T630)	Lexmark T630 (12A7360/7365/7460/7465)	✓
LEX	20g0100/0130 (T640)	Lexmark T640 Series Printers	✓

Non Virgin Inkjet Printers Cartridges

Canon	PG-40	TBA	✓
Canon	PG-50	TBA	✓
Canon	CL-41	TBA	✓
Canon	CL-51	TBA	✓
HP	HPC6657A (57)	Photosmart 100 Printers	✓
HP	HPC8728A (28)	Deskjet 3320/3420 Printers	✓
HP	HPC 9352A (22)	TBA	✓
HP	<i>New</i> HPCC640E (300 Black) +XL	TBA	✓
HP	<i>New</i> HPCC643E (300 Colour) +XL	TBA	✓
HP	HPC 8765E (338)	TBA	✓
HP	HPC 8766E (343)	TBA	✓
HP	HPC 8335E (350)	TBA	✓
HP	HP CB336E (350XL)	TBA	✓
HP	HPC 8337E (351)	TBA	✓
HP	HP CB338E (351XL)	TBA	✓